



133 Gold St.  
Worcester, MA 01608  
508-791-7552 800-821-9861  
info@addonaccessories.net

**PART 090-1807 DELUXE TRUNK BAG.** To assemble the trunk bag:

1. Open the lid.
2. Expand bag to full size.
3. Unzip the nylon lining.
4. Slide in the side support and position evenly around side.
5. Zip the nylon lining.



133 Gold St.  
Worcester, MA 01608  
508-791-7552 800-821-9861  
info@addonaccessories.net

**PART 090-1807 DELUXE TRUNK BAG.** To assemble the trunk bag:

1. Open the lid.
2. Expand bag to full size.
3. Unzip the nylon lining.
4. Slide in the side support and position evenly around side.
5. Zip the nylon lining.



133 Gold St.  
Worcester, MA 01608  
508-791-7552 800-821-9861  
info@addonaccessories.net

**PART 090-1807 DELUXE TRUNK BAG.** To assemble the trunk bag:

1. Open the lid.
2. Expand bag to full size.
3. Unzip the nylon lining.
4. Slide in the side support and position evenly around side.
5. Zip the nylon lining.



133 Gold St.  
Worcester, MA 01608  
508-791-7552 800-821-9861  
info@addonaccessories.net

**PART 090-1807 DELUXE TRUNK BAG.** To assemble the trunk bag:

1. Open the lid.
2. Expand bag to full size.
3. Unzip the nylon lining.
4. Slide in the side support and position evenly around side.
5. Zip the nylon lining.



133 Gold St.  
Worcester, MA 01608  
508-791-7552 800-821-9861  
info@addonaccessories.net

**PART 090-1807 DELUXE TRUNK BAG.** To assemble the trunk bag:

1. Open the lid.
2. Expand bag to full size.
3. Unzip the nylon lining.
4. Slide in the side support and position evenly around side.
5. Zip the nylon lining.