



Installation Instructions GL1800 CIGARETTE LIGHTER /ACCESSORY SOCKET Part Number 132-1800

NOTE: Read instructions thoroughly before installing.

GL1800 APPLICATION: Red and Black Wires

1. Carefully remove the left fairing trim accent.
2. Remove left pocket. Open pocket, press down on the center of each four lock pins in the corners using a small flathead screwdriver. Then pull upwards to take out pocket.
3. Drill a 7/8" hole in the right side diagonal panel for the 2006 to 2008 models and for the 2001 to 2005 models, drill a hole on the rear wall of the pocket. There is a mark that looks like a cross hair on the backside of the pocket and this is where to drill.
4. Unscrew the back of the lighter and insert the front of the lighter through the hole in the pocket and then screw the back of the lighter on again till the lighter is tight against the pocket.
5. Connect the wire harness to the back of the lighter with the female spade connector to the male spade connector and the female bullet connector to the screw post.
6. Locate the red male three pin plug underneath the pocket and plug the other end of the lighter wire harness into it.
7. Replace the left pocket and fairing trim accent.

NOTE: A 10 amp fuse is provided to increase the load for the light/socket. Crimp connectors are not needed:

UNIVERSAL APPLICATION Black and White Wires

1. Cut wires to remove 3 pin plug from wire harness.
2. Mount the lighter in the location desired. It requires a 7/8 inch hole. Unscrew the base from the housing, insert housing, thread base on to housing and tighten.
3. Connect the wire harness to the back of the lighter with the female spade connector to the male spade connector and the female bullet connector to the screw post.
4. Using the splice connectors provided, connect black wire to the positive and the white wires to the ground.

