




## Installation Instructions for GL1500 Tunnel Fillers Part 1646

Turn handle bars to left side. From under the fairing on right side, push the filler up into the opening with the larger part toward the front and push to the top. But do not protrude above the opening where the driver can see through. Turn the bars to the left and repeat procedure. When bars are returned to the proper position, the foam will be crushed, allow inserts to return to their original state.



133 Gold Street Worcester, MA 01608

(508)791-7552 (800)821-9861 FAX (508)793-2919

info@addonaccessories.net www.addonaccessories.net