



MOUNTING INSTRUCTIONS FOR GL1800 MUDFLAP

18741-176

18741-179

18741-180

Remove the two 5mm screws from each side of the rear fender extension. Insert the mounting plate between the two parts. Reinstall the screws and mount the flap to mounting flap.



(18741-176)