



# INSTALLATION INSTRUCTIONS

## PART 45-1203

### GL1800 CHROME FRONT LOWER COWL

**CAUTION:** Let the engine cool down before installation.

1. Place bike on center stand.
2. Remove the 6 bolts from the front cowl.
3. Remove the 2 pop plugs in the cent of the cowl.
4. Remove the cowl, remove the 2 clips and install on new cowl.
5. Replace the new cowl in the reverse manner.

