



**MOUNTING INSTRUCTIONS FOR
NOVIBE© COMFORT GRIPS
PART NUMBER 45-1243**

1. Place bike on center stand.
2. Remove anti-vibration dampers, if the bike has them.
3. Remove old grips.
4. Clean left and right side clutch and brake handlebar/sleeve.
5. Left side – Install NOVIBE© grip using adhesive to secure grip.
6. Right side –

a. If using damper, remove chrome end caps from NOVIBE© grips. Insert the socket head set screw provided with 3mm allen wrench into damper bolt hole and screw until snug (see figure 1). Install grip same as left side. Insert end chrome end cap with hole (figure 2). Be sure that there is sufficient play in the throttle and freedom of movement. Reinstall damper and double check throttle movement. If throttle is not free, back out set screw one turn. Use blue lock tight when reinstalling the damper screw.

b. If no damper is used, install grip with adhesive and do not use set screw. Install chrome end cap in figure 3 at the end of the grips.



Figure 1



Figure 2



Figure 3



Installed with damper



Installed with end cap

Shown with optional Rist Rest© Part 45-1237R