



INSTRUCTIONS FOR PART 45-1405 - DIGITAL VOLTMETER

Note: Read instructions thoroughly before installing. Drilling required.

1. Place bike on center stand.
2. Find a location for the voltmeter.
3. Mark location for to drill a hole 1 $\frac{1}{4}$ x $\frac{3}{4}$ inch.
4. Using a small saw, finish cutting out rectangles.
5. Press clamp over meter from the back.
6. Install a red and black wire to the back of the voltmeter with the Red going to the positive + and the Black going to the negative - .
7. Connect Red (positive) wire to battery and the Black wire to a ground.



133 Gold St, Worcester, MA 01608 Ph: 508-791-7552 800-821-9861 Fax 508-793-2919
email: info@addonaccessories.net