



MOUNTING INSTRUCTIONS For 45-1604 GL1800 CHROME KICKSTAND

Required tools: 14mm wrench; 8mm wrench or socket

NOTE: Read instructions thoroughly before installing.

1. Place bike on center stand.
2. Remove side stand by first removing the spring. **Warning:** Keep hand and fingers away from spring.
3. Remove locknut behind stand (14mm).
4. Remove the 8mm nut holding the switch and remove switch.
5. Remove 14mm bolt and then the side stand.
6. Install the new Chrome Kickstand in reverse order using the ORIGINAL bolt, nuts and spring or use the original bolt, nut and Add On part 45-1636, Chrome Kickstand Spring.



Add On Inc, 133 Gold St, Worcester, MA 01608 508-791-7552 800-821-9861 fax 508-793-2919 info@addonaccessories.net