



**INSTALLATION INSTRUCTIONS**  
**For the GL1800 Spoiler Light Wire Harness**  
**Part 45-1820 (Rev 8-10)**

Note: Read instruction thoroughly before installing.

1. Place bike on center stand.
2. Remove seat per service manual instructions.
3. Remove trunk lid liner by removing the screws on the inside of the trunk lid.
4. In the rear part of the bike where the seat was removed is a black boot with wire connectors. Unplug the blue 3 pin connector and plug in the 3 pin connector of part 45-1820. If the black boot is not located here, then it will be located on the top shelf above the wheel behind the rear fender.

**Note:** Test the blue 3 pin connector with a test light to ensure you have located the correct connector.

5. Run the wire up to the spoiler. Plug the 2 pin connectors from part 45-1820 between the 2 pin connectors for the spoiler light in the trunk.
6. Check the light for proper operation.
7. Reinstall trunk lid liner and seat.

133 Gold St, Worcester, MA 01608 508-791-7552 800-821-9861 fax 508-793-2919 email: [info@addonaccessories.net](mailto:info@addonaccessories.net)