



**MOUNTING INSTRUCTIONS FOR
993-190 TRUNK RELOCATION KIT for GL1200**
Fits 84-87 Interstate, Aspencade, LTD and SEI

Note: Read instructions thoroughly before installing. Drilling required.

1. Place bike on center stand.
2. Remove the four mounting screws from inside of the trunk and save.
3. Carefully, tip the trunk forward and rest on the passenger seat. The trunk's wiring harness may need to be disconnected to do this.
4. Chose one of the three mounting positions and attach the frame to the Gold Wing with spacers as shown. (Note: Three mounting holes provided different positioning. The forward most hole offers a 2 inch rearward relocation of the trunk, while the rear most hole offers 1 inch.)
5. Place the trunk on the frame and reconnect the wiring harness if necessary. Make sure wires do not get pinched.
6. Fasten the trunk to the threaded holes provided in the relocation frame with the stock mounting screws removed in Step 2 and lock washers as shown.
7. Make sure the trunk is secure and that all lights are working properly.

CAUTION: Due to the unique vibrations created by the operation of the motorcycle, the manufacturer recommends periodic inspection of accessories to secure mounting as indicated as above. Operator should not overload or abuse the product as insecure mounting may result.

Qty	Parts List
Qty	Description
1	Relocation Frame
4	M6 x 30mm Screws
8	M6 Lock Washers
4	5/8" Long Spacers

