



Installation Instructions For 45-8134ALED and 45-8134ARBLED GL1500 LED Rotor Cover Light Rings

NOTE: Read instructions thoroughly before installing. Drilling required.

1. Set bike on center stand. Disconnect battery to avoid shock. Test lights.
2. Remove the rotor covers.
 - a. Carefully pull off the left and right fender side cover. Pull forward then out.
 - b. Remove the 2 lower bolts from the left and right rotor covers with an 8mm wrench.
NOTE: DO NOT LOSE THE COLLARS.
 - c. Remove the upper bolt on the left and right chrome rotor covers with 10mm wrench.
 - d. Remove rotor covers and lay on a flat surface.
3. Clean the edges of the rotor cover where the light rings will go. Use soap and water or other mild cleaner and wipe dry with a non-abrasive cloth.
4. Position the chrome light rings on the rotor covers with the wire leads at the top of the rotor cover. There should be a left and right. When satisfied with the position, mark rotor covers, drill holes. Hold ring down firmly and carefully drill 4 mounting holes using a 9/64 inch bit.
5. Using the hardware provided, attach each chrome light ring.
6. Reinstall rotor covers.
7. Connect the black wires to ground. Connect the green wires to your choice of power source and insulate the connection.

NOTE: When routing the wires, keep them away from all moving parts.

